


# Instructions for adding crystal to your acid neutralizer



## Use Crystal \_\_\_\_ in your Acid Neutralizer.

1. Turn inlet and outlet valves off
2. Open boiler drain to relieve tank pressure
3. Open tank cap & drain approximately 15" of water from tank
4. Pour Crystal in top opening and fill to full line  
Don't fill any higher than 15" from top of tank- \*READ BELOW WARNING
5. Open inlet valve and fill tank full with water
6. Replace tank cap and hand tighten  
If oring on bottom of cap appears dry, lubricate with a food grade lubricant
8. Open inlet and outlet valves to complete service

**\* WARNING - Never ad more than 3" inches of Crystal to tank at one time. If 3" doesn't fill tank to full mark, wait one week or more to ad more. Proceed with these steps until Crystal level is at full mark.**



Any Questions Call (717) 866-5388